



Digital Welding Gauge

- Holds either the zero setting or measured value at any position for differential measurements.
- Has a serial output to interface with a computer or printer to process data.
- Automatically turns on by moving the main scale or by pressing ON/OFF key.
- Automatically turns off after 4 minutes of inactivity conserving battery power.

Part No	Description
CAT18	Digital Welding Gauge